


LED Wine Glass Light
NEWSTAR LED CO., LIMITED

Mi·Light



0186

www.newstarleds.com

LED Wine Glass Light


User Instruction

1. Specification

- Lithium battery:3.7V/1400mAh
- Power: 2W
- Color: RGB+W
- RF Frequency: 2.4GHz
- Control Distance: 30 Meters
- Size:183mm(length)* 80mm(diameter)
- Adapter: 5V==500mA

2. Basic Functions

- Put the battery into charge for at least 10 seconds for the first use.The battery needs 2-3 hours for a full charge, the white will blink 5 times after the battery is fully charged.
- Basic functions as below:



3.Link&Unlink

- Link: Press **OFF** button on the light, the light goes off, then press **ON** button on the light, the light goes on, within 3 seconds press any zone button on the remote 3 times quickly , the green light blinks, the link is done. You are free to link any light to any zone.
- Unlink: Press **OFF** button on the light, the light goes off,then press **ON** button on the light, the light goes on, within 3 seconds press the linked zone button on the remote 5 times quickly , the red light blinks, the unlink is done.

4.Attention:

- Charge the battery for the first time use.
- Avoid high temperature or moisture.
- Avoid dropping off.
- Disassembly only by the professionals.

